


PATTERN PROJECTOR LIGHTS

CIVIC

GENERAL VIEW



FOR YOUR SAFETY (Read carefully)

Introduction of Symbol Messages

- These symbols warn you about the possible hazards and explain how to avoid them. And give you some advices.

⚠ DANGER

You will be killed or seriously hurt if you do not follow the instructions.

⚠ WARNING

You can be killed or seriously hurt if you do not follow the instructions.

⚠ CAUTION

You can be hurt if you do not follow the instructions.

NOTICE


Gives advice to prevent damage to the product.
Gives helpful information or instructions to be followed in using the product.




Indicates prohibited actions.

Introduction of Icons

- These icons indicate the working place and the worker's vision.



The place for the vehicle.



The place for the instrument panel.

- These icons indicate the necessary things for your safety and the work.



Wear eye protection.



Wear heavy gloves.



Work with an assistant.



Place the part on a blanket.



Remove any burrs.



Use the touch-up paint and dry.



Keep the parts and give it to the customer.
(Not use)



Press firmly.



Tighten by specified torque.




Work perpendicularly.



Clean with the contact cleaner.


Wire Harness Routing Precaution




Do not clamp the
accessory harness and
SRS harness together.
(except for instruction
cases).




Connect the connectors
and terminals securely
until they lock.



Do not pull the harness to
disconnect the connectors.



Reinstall the connectors to
the original positions if
they are removed.




Do not pull the harness
strongly.



Secure the accessory
harness to the specified
position, not to hang down.



Do not pinch the harness
with the parts.



Cut off the excess of the
wire ties.

Safety: General

- Observe all safety notes and precautions described in the Shop Manual in addition to those described in this Installation Instructions. Be extremely careful for your safety and safety of others particularly.
- Be careful not to damage the vehicle and the parts.
- Be extremely careful to the handling of the retaining tabs and clips particularly.
- Note the locations of the parts before removing them so that they can be reinstalled in their original positions properly.
- The illustrations may differ a little from the actual accessories for the design change of the vehicle.

Safety: For Electric Parts














- Do not perform the installation of the accessories with having connected negative cable of the battery.

Safety: For the Accessory

- **Always use the parts and tools specified in the installation instructions.**
- **Do not perform installation work and attaching work at the place where gets the direct rays of the sun or the dust appears.**
- **Always install these accessories at the ambient air temperature 15°C (60°F) or above.**
- **Heat the accessories and bonding surfaces if the ambient air temperature is below 15°C (60°F).**
- **Attach the accessories by pressing it firmly with the palm of your hand. Be careful not to damage the accessories and the vehicle parts.**
- **Carefully place the double-sided adhesive tape on the proper position. Once the double-sided adhesive tape touches the surface, do not try to detach and relocate it. If you attempt to move after it touches the surface, you will damage the part before the adhesive will give way.**

PARTS LIST

Pattern Projector Lights Kit

Right light (Identification mark: R) 	Left light (Identification mark: L) 	Harnesses (2) 	Wire ties (14) 
Self-tapping screws (2) 	Urethane tapes (4) 	Fuse label 	Aluminum tapes (2) 
Joint connector covers A (white) (4) 	Joint connector cases A (white) (4) 	Joint connector covers B (sky blue) (2) 	Joint connector cases B (sky blue) (2) 
Template 			

TOOLS AND SUPPLIES REQUIRED

- Phillips screwdriver
 - Electrical tape
 - Ratchet
 - Pushpin
 - Scissors
 - File
 - Eye protection
(face shield, safety goggles, etc.)
- 10 mm Open end wrench
 - Contact cleaner
 - 10 mm Socket
 - Drill
 - Flat-tip screwdriver
 - Handy remover
 - 3 mm, 6 mm, 8 mm, and 11 mm
Drill bits
- Nippers
 - Shop towel
 - Pliers
 - Masking tape
 - Tape
 - Ruler


INSTALLATION

How to Use the Contact Cleaner

- Using contact cleaner on a shop towel, thoroughly clean the areas where the accessories will be attached.

NOTICE

- Always use the contact cleaner.
- Do not apply the cleaner to the object of the work directly.
- Allow to dry completely the cleaned areas before attachment work.






Disconnecting the Battery Cable

- Perform the works before disconnecting the negative cable from the battery as shown below.
- Make sure if you have the anti-theft code for the audio/navigation system. Record some settings of the vehicle if necessary.
- Disconnect the negative cable from the battery.

NOTICE

- For Hybrid vehicle, make sure not to disconnect the negative cable from the battery three minutes after turning the power switch to OFF.




QCD0502BM

Removing the Vehicle Parts

- Attach the tapes to protect the vehicle.


NOTICE

- Do not remove the tapes until after the reinstallation.



TAPES

RIGHT FRONT
DOOR LINING




QL21301BU

- Remove the right front door switch panel.


FLAT-TIP
SCREWDRIVER

CUTOUT



CLIP

8 RETAINING
TABS




VEHICLE
CONNECTORS

RIGHT FRONT DOOR
SWITCH PANEL



QKN0502CU

6. Release the right front door lining.




QKN0503DU

7. Remove the right front door lining.



QL00808AU


8. Repeat the same procedures on the other side.



Q9D1013AM


Installing the Lights

9. Cut the template.




QKN0505BU

10. Attach the urethane tape.




QKN0506BU

11. Secure the template.




12. Pierce the right front door lining.




13. Remove the template R.


14. Drill the right front door lining.




15. Install the light.



16. Secure the right light harness.




17. Repeat the same procedures on the other side.




Routing the Harness

18. Attach the fuse labels.




19. Secure the harness.




20. Cut out the tape.

NOTICE
<ul style="list-style-type: none">• Be careful not to damage the vehicle harness.



NOTICE
<ul style="list-style-type: none">• Make sure to correctly connect the cord.



1 Make sure to secure in second lock position.

Approx. 40 mm (Approx. 1.6 in.)

ACCESSORY CORD

2 ELECTRICAL TAPE (Insulate.)


3 Use the new joint connector to secure the accessory cord to the correct cord.

QL21302BU

NOTICE
<ul style="list-style-type: none"> • Wrap the electrical tape around the tubes and tapes of the vehicle harness.



NOTICE
<ul style="list-style-type: none">• Be careful not to damage the harness.




QL30403AU

- 24. Disconnect the vehicle connector.
- 25. Cut out the tape.

NOTICE

- Be careful not to damage the vehicle harness.




QL00515BU

- 26. Connect the harness cord.
(Refer to “How to Use the Joint Connector” in step 21.)

NOTICE


- Make sure to correctly connect the cord.



- 27. Secure the harness cord.


NOTICE

- Wrap the electrical tape around the tubes and tapes of the vehicle harness.




QG71729AJ

28. Wrap the urethane tape.



QM30413AU

29. Reconnect the vehicle connector.
30. Secure the harness.





QL00516CU

31. Disconnect the vehicle connector.
32. Cut out the tape.

NOTICE

- Be careful not to damage the vehicle harness.




QM30405AU


33. Connect the harness cord.
(Refer to "How to Use the Joint Connector" in step 21.)

NOTICE

- Make sure to correctly connect the cord.



<HARNESS SIDE VIEW>



VEHICLE 14-PIN
CONNECTOR

SAME
COLOR CORD
(Do not connect.)


QM30406BU

VEHICLE CORD:
BLACK
ACCESSORY CORD:
BLACK
JOINT CONNECTOR A
(white)

34. Secure the harness cord.


NOTICE

- Wrap the electrical tape around the tubes and tapes of the vehicle harness.



QH00207AT

35. Wrap the urethane tape.




QJ22517AJ

36. Reconnect the vehicle connector.

37. Secure the harness.


NOTICE

- Be careful not to damage the harness.




QM30407AU

38. Connect the harness connector.
39. Reinstall the right front door lining.




40. Secure the harness.



41. Cut out the tape.

NOTICE


- Be careful not to damage the vehicle harness.



42. Connect the harness cord.
(Refer to "How to Use the Joint Connector" in step 21.)

NOTICE


- Make sure to correctly connect the cord.



43. Secure the harness cord.

NOTICE

- Wrap the electrical tape around the tubes and tapes of the vehicle harness.






QJ80163AR

44. Secure the harness and fuse case.

NOTICE

- Be careful not to damage the harness.



OTHER ACCESSORY HARNESS WIRE TIE WIRE TIE


QL00519BU

45. Disconnect the vehicle connector.

46. Cut out the tape.

NOTICE

- Be careful not to damage the vehicle harness.




QL00520BU

47. Connect the harness cord.
(Refer to "How to Use the Joint Connector" in step 21.)

NOTICE


- Make sure to correctly connect the cord.



48. Secure the harness cord.


NOTICE

- Wrap the electrical tape around the tubes and tapes of the vehicle harness.




QG71729AJ

49. Wrap the urethane tape.



QM30413AU



50. Reconnect the vehicle connector.
51. Secure the harness.



- 52. Disconnect the vehicle connector.
- 53. Cut out the tape.

NOTICE

- Be careful not to damage the vehicle harness.




QM30409AU

- 54. Connect the harness cord.
(Refer to “How to Use the Joint Connector” in step 21.)

NOTICE


- Make sure to correctly connect the cord.



- 55. Secure the harness cord.


NOTICE

- Wrap the electrical tape around the tubes and tapes of the vehicle harness.



QJ80163AR

56. Wrap the urethane tape.



URETHANE TAPE
(cut in step 49)


QM30411AU

57. Reconnect the vehicle connector.

58. Secure the harness.

NOTICE


- Be careful not to damage the harness.



QM30412AU

59. Connect the harness connector.

60. Reinstall the left front door lining.



LEFT FRONT
DOOR LINING

LEFT LIGHT 4-PIN
CONNECTOR




QKN0527AU

Check After Installation

61. Check that all parts are routed and installed properly.

NOTICE

- Check that the harnesses are not pushed, not pulled and not pinched.
- Check that all clamps and wire ties are installed securely.




Q060706CM

Reinstalling the All Removed Parts

62. Reinstall all removed parts.


NOTICE

- Be extremely careful not to damage the vehicle parts, pinch the harnesses.
- Make sure to secure the retaining tabs and clips properly to avoid separation.



Operation Check

63. Reconnect the negative cable to the battery.



64. Check that the light comes on by opening a door.

65. Check that the light comes off by closing a door.

Vehicle Check

66. Check that the electric accessories and systems operate properly.

67. Press and hold the audio power button for two seconds, or enter anti-theft code for the audio/navigation system.

68. Reset the memory of each equipment and restore the positions of those control knobs.

